

User Manual

Thank you for purchasing our product. Please read all operating instructions carefully before use.

Never load the scale with more than the maximal capacity. Overloading will permanently damage it!

Avoid any exposure to extreme heat or cold, your scale will work better when operated at normal room temperature. Always allow the scale to acclimate to normal room temperature for at least one hour before use.

- Keep your scale in a clean environment.

Dust, dirt, moisture, vibration, air currents and a close distance to other electronic equipment can all cause an adverse effect on the reliability and accuracy of your scale.

Handle with care. Avoid shaking or dropping the scale.

Use the scale on a hard-flat surface.

I. Operation

Place Scale on a horizontal flat surface.

1. Press "ON/OFF" key.
2. Wait until [0.000] is displayed.
3. Put the object(s) on the weighing platform.

II. Mode

1. Using the "MODE" key, you can switch between the weighing units.
2. The weighing unit will display the unit you used last time.

III. Tare Weighing.

1. Turn on scale as described above.
2. Place the "tare item" on the platform.
3. Press "TARE" key and wait until [0.000].
4. Add the "net-weight- item"

IV. Calibration

Use two 20g calibration weights to calibrate the scale.

1. Turn on the scale.
2. Press "MODE" key and hold for 4 seconds until showing "cal"
3. Press "MODE" key again, "cal" will blink three times and display "20.000".
4. Place a 20g calibration weight on the platform until displays "40.000g"
5. Place another 20g calibration weight on the platform until display "PASS".

6. Take away the calibration weights; you can use the scale normally now. Repeat this process when your scale works wrong.

V. Counting function

1. Turn on the scale and wait until the LCD displays "0.000".
2. Put a certain amount of the item you want to weigh onto the platform of the scale.
3. Press and hold "PCS" key, the LCD will display "25"
4. Press "MODE" key you can change numbers "25-50-75-100"
5. Select one number and press "PCS" key to confirm. The LCD displays "PCS" on the corner.
6. Now you can use this function to count your weighing objects.

VI. Specifications

Max capacity: 250ct
Accuracy: ±0.4 0g, 0.005ct > 40g, 0.01ct
Units: g/oz/ozt/dwt/ct/gn
Auto calibration
Tare full capacity
Auto off function
Operation temperature: 1 0-30°C
Power: 6V/4x "AAA" Alkaline Batteries)
Adapter: AC 11 0v- 220v DC6v 200mA
Product dimensions: 135x90x65 mm
Product net weight: 195g

Optima Home Scales QUARTZ User Manual