

GAMA

Thank you for purchasing our pocket scale. Please read all operating instructions carefully before use. This electronic scale is a precision instrument. With normal care and proper treatment, it will provide years of reliable service. Please use only high-quality AAA batteries.

I. Operation

Place Scale on a horizontal flat surface

1. Press ON/OFF key.
2. Wait until [0.0] is displayed
3. Put the object(s) on the weighing platform
4. Using the MODE key, you can switch between the units

II. Tare Weighing

1. Turn on scale as described above
2. Place the "tare item" on the platform
3. Press TARE and wait until [0.0] is displayed
4. Add the "net-weight-item".

III. CALIBRATION

Turn the scale on by pressing the ON/OFF key, wait for the display to show "0.0g" or "0.00g", then press and hold the MODE key until the display shows "CAL", then release. Press the MODE key again, the display will flash "CAL" followed by the required calibration weight. DO NOT ATTEMPT CALIBRATION WITHOUT THE CORRECT CALIBRATION WEIGHT. Place the required calibration weight on the center of the platform. The display will show "PASS" then return to normal weighing mode. Calibration is complete!

Repeat the process if necessary.