

OHS JAVA Manual Instruction

Please read this instruction manual carefully before operating the scale, to ensure the precision and durability of the scale.

Features

- Four Highly Sensitive Load-cell
- Four comfortable buttons
- Backlight display
- Weighing Mode and timer Mode
- Capacity: 3kg
- Graduation: 0.1g
- Auto Zero Tracking
- Overload Indication
- Battery Low Voltage Indication
- Auto power off in 4min

Battery

2 x 1.5VAAA Batteries

Please insert into the bottom battery compartment.

Operation

Weighing mode

Place the scale on a hard-flat surface.

If the display does not show zero, please press the "TARE" button to go back to zero then continue to weigh. When the scale is in weighing mode, press "START/STOP" key to start/stop the timer function;



Unit Conversions:

There are five units "oz→lb→g→g/ml→ml", press the "UNITS" button on the scale to choose your desired mode.

Over weight

If an overweight item is placed on the platform, the LCD will show "EEEE" to alert you the scale is overloaded.



Tare Function :


When you use a bowl/cup for weighing, put the empty bowl/cup on the scale platform, press the "TARE" button to display "0", then fill the target item in the bowl/cup, to get the net weight of the target item.

Timer Function:

To use the timer function, press the "START / STOP" button to start timing. Press "Stop" to pause time, press it a third time to resume from paused timer. The timer can be set up to 99 minutes 59 seconds.

To reset the timer, press the "START/STOP" button and hold for three seconds and the timer will return to "Zero", or you can shut off the scale and then power it on again to restart the timer.

Low battery indication:

If the battery is low, the display shows "  "and "Lo". Please replace the batteries.



Security caution

1. Please don't place overweight articles on platform to avoid permanent damage.
2. After weighing, clear the weighing platform. Please don't continuously place articles on the product's weighing platform.
3. The loadcell used by this product cannot be reused. Please don't short-circuit, dismantle or discard the loadcell into fire. Please keep them from infants to avoid swallowing
4. The product is only designed as personal or family use and not for medical treatment or commercial use.
5. Please protect the product from pounding, being moistened or stained with dust and chemicals.
6. Keep it away from all heat sources such as furnace, oven, microwave oven, and other heating appliances. If you find an abnormality in the function of the device, first check loadcell. Replace the loadcell if needed. The maintenance work should be conducted by a person authorized by the dealer.
7. If you find the reading is unstable on the liquid crystal panel, check the edge of the weighing platform for foreign matter stuck between the weighing platform and base.
8. Please place the scale on a horizontal flat/table to accurately measure weight.
9. Make sure the display is at zero, before you start weighing.
10. Place the target weighing item in the center of the platform to receive a proper measurement of weight.

Patent products, copyright infringement !