

Optima Home Scales

Titanium User Manual

To get the best out of your new scale, please read this brochure carefully before using it for the first time. We also recommend that you keep the instructions for future reference, so that you can have a checklist of the functions of your scale.

WARRANTY TERMS

The weighing scales are covered by a 10-year guarantee that begins from the purchase date. Due to the constant development of our products in terms of function and design, we reserve the right to make changes to the product without warning.

PRIOR TO FIRST USE

Remove the battery cover on the underside of the scale and insert the 2 new AAA batteries that you will find within the packaging. Make sure that the batteries are correctly inserted respecting the correct polarities illustrated on the battery cover and replace the cover. Please ensure that you remove the transparent plastic protective cover on the plate of the weighing scales.

Calibration step – Do NOT attempt without the proper calibration weight present!

Calibration allows you to balance the scale to obtain proper measure.

1. Press the ON button of the scale. Do not put any weight on the tray.
2. Press « M » button and keep it pressed for 2 sec until the display shows « CAL ».
3. Press « M » button again and it will display « CAL » blinking, then the calibration weight 2000g.
4. Put a 2000-gram weight on the middle of the tray. The display will show « PASS ».
5. Remove the weight from the tray and turn OFF the scale. Calibration is complete.

USE

1. Place the scale on a level surface (the sensors in the rubber feet only function properly when resting on a level surface)
2. Switch the scale on by pressing the “O” button and the value “0.0” appears on the display.
3. The display shows the measuring units used g/gn/oz/ozt/dwt/ct. To modify the measuring units, press in sequence the “M” button.
4. Place the object you wish to weigh on the weighing platform.
5. Wait until the display is stable, and then read the weight on the display.
6. Use the tare function of the scale to weigh several consecutive objects in the following manner:
 - a) Place the object you wish to weigh on the weighing platform.
 - c) Press the “T” button once to reset the weight. The weight of the first object will now be displayed as zero, even though it remains on the weighing platform.
 - d) Place the next object on the weighing platform (e.g. add a product into the bowl) and read the weight when the display is stable. The weight shown on the display is that of the product which has just been added following the use of the Tare function.

Adjust the auto shut-off time

Turn the scale on. “0.00” will be shown on the display. Hold the “T” button and the display will show “00”. Press the “M” button to adjust the auto shut-off time. “00” means manual shut-off. “60” means it will turn off after 1 minute of non-use. “120” means it will turn off after 2 minutes of non-use. “180” means it will turn off after 3 minutes of non-use. Then press the “ON/ OFF” button to confirm it. The display will show “PASS” to indicate successful setting.

SAFETY MEASURES

1. Incorrect use of the scale may damage it.
2. Use only for its intended purpose. The manufacturer is not responsible for any injury or damage from incorrect use or handling.
3. For domestic use only.
4. Do not place the scale on carpet or uneven surface.
5. Do not place or store near a powerful heat source or in a damp environment.
6. Do not immerse in water or allow the scale to get wet.
7. Do not expose to direct sunlight for long periods.
8. Remove the batteries if the scale remains unused for a prolonged period.
9. Do not attempt to weigh objects which exceed the scales maximum capacity of 2kg/ 70,54 oz/30864gn
10. If the scale has been damaged, it should be inspected and if necessary repairs made. Modifications to the scale will void the warranty.

NOTE

1. If you try to weigh something heavier than the scale can bear (more than 2kg/ 70,54 oz/30864gn) the display will show "O-LD" (Overload).
2. The text "LO" on the display indicates that the 2xAAA batteries are no longer active, please proceed in substituting them.
3. If you wish to move the scale, you should turn it off before moving.
4. Do not switch it on again until it is placed correctly on a level surface. The sensor only functions properly when resting on a level surface.

CLEANING

1. Never immerse the scale in water.
2. No water must penetrate the body of the weighing scales.
3. Clean the scale by wiping it with a clean and damp cloth.
4. A little detergent can be added if the scale is heavily soiled but use care when cleaning the scale, as it may damage the outside surfaces of the scale.
5. Leave the scale to dry completely before re-using.

REPLACING THE BATTERIES

1. Remove the cover on the back of the scale, take out the batteries and insert two new AAA batteries observing the correct polarity indicated in the battery compartment and close the lid.
2. If the symbol "LO" is shown on the display, or if you cannot switch on the scale, or it does not work correctly, you should replace the batteries.
3. Leaking batteries must be replaced immediately, as these can damage the scale.
4. Used batteries should, if possible, be deposited in a special container for used batteries or at a recycling point.
5. Remove the batteries if the scale is not used for a prolonged period.

SPECIFICATIONS:

1. Capacity: 2kg/ 70,54 oz/30864gn
2. Graduation:0,1g
3. measuring units: g/gn/oz/ozt/dwt/ct
4. Battery: 2xAAA